

Reset the MAINT REQD Light

1. Get to Ig-On by pressing the POWER button twice, no foot on the brake
2. Make sure the odometer displays ODO *NOT TRIP A or TRIP B*. Press the ODO TRIP button to get to ODO if not already there.
3. Press POWER button once to turn off your Prius
4. Put your foot on the brake, press and hold the ODO TRIP button in while you press the POWER button until car goes to READY
5. Hold the ODO TRIP button in until all the flashing lines on the odometer go away, it briefly flashes 000000, and the mileage returns and the MAINT REQD light turns off
6. Power down the car or go for a drive, you're done.